

Electrochemical Li recovery strategy from Li-ion battery black mass Pier Giorgio Schiavi

Department of chemistry Sapienza University of Rome piergiorgio.schiavi@uniroma1.it

Brussels 12th December 2024









RHINOCEROS Objective

• The objective of Rhinoceros is to develop, improve, and demonstrate, in an industrially relevant environment, an economically and environmentally viable route for re-using, and recycling End-of-Life (EoL) Electric Vehicles (EV) and stationary energy storage Lithium-Ion Batteries (LIBs).





Funded by the European Union under Grant Agreement No 101069685. Views and opinions expressed are however those of the author(s) only and do not necessarily reflect those of the European Union or the European Climate, Infrastructure and Environment Executive Agency (CINEA). Neither the European Union nor the granting authority can be held responsible for them.







Electrochemical recovery of Lithium: concept

• This activity aims to develop an electrochemical process for selective extraction of Li from the EoL LIB black mass, mimicking the charging process of a standard LIB.







Potentiostatic delithiation

• Li extraction yields of up to 82% were achieved with electrodic powders from EoL LIBs, while commercial electrodic powders reached 99%.





Role of impurities: Cu





RHINO-3 – Black mass		
	average [mg/g]	st.dev [mg/g]
Со	75	3
Ni	92	1
Mn	88	6
Li	31	1
Al	6	5
Cu	13	1
Fe	1	0

6

Theorethical charge for the complete oxidation of Cu \sim 40 C/g

- corresponding to ~ 9 % of theoretical charge imposed for the oxidation of NMC in R3 (493 C/g)
- corresponding to ~ 3% of total charge in the case of 200% charge excess respect theoretical charge for NMC oxidation (1480 C/g)





Role of impurities: graphite and super P conductive carbon







Li selectivity towards Ni, Mn and Co



Metal	Extraction %	
Со	0.04±0.005	
Ni	0.07±0.009	
Mn	0.02±0.002	

Experimental Procedure:

- Delithiation of Rhino 3 at 2V with a 200% charge excess (6 replicates).
- ICP-OES analysis of the electrolytes (no metals detected).
- Digestion of counter electrodes used during delithiation, followed by analysis with ICP-OES





Conclusions

- Efficiency: Rhino 3 displays lower extraction yields (82%) and faradaic efficiency to respect commercial cathode materials (close to 100%). Super P oxidation could explain the lower Li extraction
- Selectivity: Ni, Mn and Co are not extracted
- Scaling up: evaluating an alternative approach that enables the treatment of larger quantities of powder <u>without replicating the manufacturing process of LIB</u> <u>electrodes!</u>









Thanks for your attention!

piergiorgio.schiavi@uniroma1.it



www.rhinoceros-project.eu







